



ANALYSIS REPORT No. IAC-R11-0754-1-A01

Amendment to the IAC-R11-0754-1 Analysis Report

History amendments

Edition Dated		Description of amendment	paragraphs concerned
01	03/08/2011	Simplify the page layout on a page and integrate the percentages on the results table	results





ANALYSIS REPORT No. IAC-R11-0754-A01

Amendment to the IAC-R11-0754 Analysis Report

Business : BEEWAIR

Address: 3 alley TEPPE BP 6003 71012 MACON CEDEX FRANCE

To the attention of : Mrs. Chardigny

File number	: 2011-0754			
Order number	: 112207-1 + 112207-2			
Date Order	: 22/07/2011			
Date samples received	: 04/07/2011			

Date Issue Report: 3-Aug-11

Report Writer

Soria HAMDAOUI

Spiatter.

approval

Christian Gimenez

Intertek Analytical Services FRANCE

Industrial Campus - Company area - 2nd floor Route Demigny 71102 Chalon sur Saône Cedex Tel 03 85 99 12 76 Fax 03 85 99 12 88 Email chalon@intertek.com

The report relates only to the samples tested

The report must not be reproduced even in part without the approval of the Laboratory

page 2/3



Date early tests: 08/07/2011

Date end of the tests: 22/07/2011

Purpose of the study :

Study of the effectiveness of decontamination in air

Customer Reference samples :

BW60

Analysis Protocol :

Contact Time: 1 hour, 2 hours, 4 hours Bacteria

: Staphylococcus aureus

Escherichia coli Total germs (Bacteria) Mold

air manifold: Sampl'air (AES Chemunex) Total volume of collected air: 60 m 3 for total bacteria and

molds

75 m₃ for pathogens (S.aureus and E.coli)

An ambient air negative control is prepared without using BW60.

Analysis results :

Counting in UFC	то	1H	Reduction logarithmic	%	2H	Logarithmic reduction	4H	Reduction logarithmic	%
negative control	/	1.2 10E4	1		2.0 10E4	1	3.5 10E4	1	
bacteria	/	20	2.8	> 95	17	3.1	22	3.2	> 99.9
molds	/	46	2.4	> 95	18	3.0	24	3.2	> 99.9
S.aureus	1.2 10E5	17	3.9	> 99.9 /		1	18	3.8	> 99.9
E.coli	1.6 10E5	2	4.9	> 99.9 /		1	4	4.6	> 99.9

CFU = colony forming unit

Conclusion:

The device BW60 showed a significant reduction in microbial viability in 1 hour, 2 hours and 4 hours of contact for total bacteria, mold and the intended pathogens and a volume of at least 60 m³ for total bacteria and mold.

END OF REPORT

The report relates only to the samples tested

The report must not be reproduced even in part without the approval of the Laboratory